NESANS

Conveyor Belt Tracking Problems: Root Cause Analysis and Permanent Solutions

Diagnose and fix conveyor belt tracking issues permanently. Covers idler alignment, load centering, and tension adjustment for aggregate plant conveyors.

Author: Sivabalan Selvarajan

Published: January 25, 2026

Reading Time: 3 minutes

Belt tracking problems cause 70% of conveyor-related downtime and are responsible for premature belt replacement, spillage cleanup costs, and safety incidents. Yet most tracking issues stem from just five root causes that can be systematically identified and corrected. This guide provides a diagnostic framework for identifying tracking problems at their source rather than chasing symptoms with endless idler adjustments.

Understanding Belt Tracking

A properly tracking belt maintains center alignment within ±25mm across its full length. Misalignment beyond this threshold causes:

- Belt edge damage and fraying

- Material spillage at transfer points

- Increased idler and pulley wear

- Structural damage to conveyor frame
- Fire risk from friction on structure

Root Cause Analysis Framework

The Five Primary Causes

ROOT CAUSE	FREQUENCY	DIAGNOSTIC SIGNS	LOCATION PATTERN
Off-center loading	35%	Mistracking after load point only	Carry side after loading
Pulley misalignment	25%	Consistent run-off at pulleys	Near head, tail, or bend pulley
Belt splice issue	15%	Mistracking cycles with belt rotation	Varies with splice position
Idler misalignment	15%	Progressive drift along conveyor	Carry or return side specific
Belt damage	10%	Erratic, unpredictable tracking	Variable

Diagnostic Procedure

Step 1: Observe Full Belt Cycle

- Run conveyor unloaded for minimum 3 belt cycles
- Mark a reference point on belt edge
- Observe if mistracking follows specific belt section
- If yes: splice or belt damage likely
- If no: proceed to structure/alignment checks

Step 2: Loaded vs. Unloaded Comparison

- If tracks well empty but mistrracks loaded: loading problem
- If mistracks empty and loaded: structural/alignment issue

Step 3: Systematic Location Check

CHECK POINT	ALIGNMENT METHOD	TOLERANCE
Head pulley	Piano wire or laser	Perpendicular ±3mm per meter width
Tail pulley	Piano wire or laser	Perpendicular ±3mm per meter width
Snub/bend pulleys	Piano wire reference	Parallel to drive pulley
Carry idlers	Square to frame, level	±6mm across width
Return idlers	Square to frame	±6mm across width

Cause-Specific Corrections

Off-Center Loading

- Adjust feed chute to center material flow
- Install impact bed centered on belt
- Check upstream conveyor discharge alignment
- Install training idlers after loading zone

Pulley Misalignment

- Loosen mounting bolts
- Align using piano wire or laser
- Verify perpendicular to belt travel
- Retorque and recheck

Belt Splice Issues

- Check splice alignment (should be perpendicular)
- Verify splice tension uniformity
- Replace crooked or failing splice

Training Idler Application

TYPE	APPLICATION	ADJUSTMENT
Self-aligning pivot	General tracking	Automatic response
Side guide rollers	Edge containment	Set 25mm gap from edge
V-return idlers	Return side tracking	Angle 2-3° toward center

Prevention Protocol

INSPECTION ITEM	FREQUENCY	ACTION
Belt edge condition	Daily	Report fraying or damage
Tracking observation	Daily	Note drift patterns
Pulley alignment	Quarterly	Verify with instruments
Idler alignment	Quarterly	Square check
Splice condition	Monthly	Visual inspection

Conclusion

Effective belt tracking requires systematic root cause identification rather than reactive adjustment. Use the diagnostic framework to identify the actual cause, apply appropriate corrections, and implement preventive monitoring. This approach resolves tracking issues permanently rather than creating endless adjustment cycles that never address underlying problems.

Topics: #Conveying #Maintenance #Troubleshooting #belt conveyor

NESANS