



## MAINTENANCE TIPS

# Mobile Cone Crusher Track Maintenance: Extend Undercarriage Life by 40%

Proper track maintenance for mobile cone crushers. Track tension, sprocket wear, and roller inspection to maximize undercarriage investment.

**Author:** Sivabalan  
Selvarajan

**Published:** February 12,  
2026

**Reading Time:** 3  
minutes

Track undercarriage represents 15-25% of mobile crusher capital cost, yet track maintenance is often neglected until failures force expensive emergency repairs. A well-maintained track system achieves 8,000-12,000 operating hours; a neglected one may require replacement at 4,000 hours. This guide establishes the inspection and maintenance protocols that maximize undercarriage life while ensuring safe, reliable mobility.

## Undercarriage Component Overview

COMPONENT	FUNCTION	TYPICAL LIFE (HOURS)	REPLACEMENT COST
Track chain/links	Support and drive transmission	6000-10000	₹8-15 lakhs
Track pads/shoes	Ground contact, traction	4000-8000	₹3-6 lakhs

COMPONENT	FUNCTION	TYPICAL LIFE (HOURS)	REPLACEMENT COST
Carrier rollers	Support track on top run	6000-10000	₹15,000-30,000 each
Track rollers	Support track on bottom	6000-10000	₹20,000-40,000 each
Idler wheels	Guide and tension track	6000-10000	₹50,000-1 lakh
Sprocket	Drive engagement	6000-12000	₹60,000-1.5 lakhs
Final drive	Power transmission	10000-15000	₹3-8 lakhs

## Daily Inspection Protocol

CHECK	METHOD	NORMAL	ACTION REQUIRED
Track tension	Measure sag at center	40-60mm (steel tracks)	Adjust if outside range
Track pad condition	Visual inspection	>50% grouser height	Plan replacement at 25%
Roller rotation	Spin by hand	Smooth, free rotation	Grinding = bearing failure
Oil leaks	Visual under rollers	Dry	Replace leaking rollers
Foreign objects	Visual full track circuit	Clear	Remove any debris

## Track Tension Adjustment

### Tension Guidelines

TRACK TYPE	CORRECT SAG	CONSEQUENCE TOO LOOSE	CONSEQUENCE TOO TIGHT
Steel tracks	40-60mm	Derailment, accelerated wear	Increased component stress
Rubber tracks	20-40mm	Track slip, drive issues	Belt damage, motor overload

### Adjustment Procedure

1. Park on level, firm ground

2. Measure sag at center span between idler and first roller
3. If loose: pump grease into tension cylinder
4. If tight: release grease from tension cylinder (carefully!)
5. Remeasure and repeat until within specification

## Weekly Inspections

COMPONENT	INSPECTION	MEASUREMENT	REPLACE WHEN
Track link pins	Check for movement	Visual/touch	Any lateral play
Sprocket teeth	Measure tooth height	Gauge or caliper	<50% original height
Track shoe bolts	Torque check sample	Torque wrench	Retorque if loose
Final drive oil	Level check	Sight glass/dipstick	Top up if low
Track frame	Crack inspection	Visual	Weld repair if cracked

## Operating Practices for Extended Life

PRACTICE	IMPACT ON LIFE	IMPLEMENTATION
Minimize track slewing	+30% sprocket life	Use proper turning technique
Avoid excessive travel	+20% overall life	Position well initially
Keep out of water/mud	+40% bearing life	Select firm, dry sites
Match speed to conditions	+15% component life	Slow on rough terrain
Clean tracks periodically	+10% overall life	Remove packed material

## Wear Measurement

COMPONENT	MEASUREMENT POINT	NEW DIMENSION	REPLACE AT
Track shoe grouser	Height above shoe	35-45mm	<15mm
Link height	Rail height	Per OEM spec	75% of new
Pin/bushing	Outside diameter	Per OEM spec	Internal wear indicator
Roller tread	Tread width	Per OEM spec	<60% of new

## Final Drive Maintenance

SERVICE	INTERVAL	SPECIFICATION
Oil level check	Weekly	At filler level when cold
Oil change	1000 hours or annually	SAE 80W-90 or per OEM
Magnetic plug check	At oil change	Excessive metal = problem
Seal inspection	Weekly	No visible leakage

## Conclusion

Track undercarriage maintenance requires consistent attention to tension, component condition, and operating practices. The daily 10-minute inspection and weekly measurement protocol prevent minor wear from becoming major failures. Plants that maintain undercarriage systematically achieve double the component life of those practicing reactive maintenance—a difference measured in lakhs of rupees over equipment lifetime.

### Topics:

[#Mobile Crusher](#)
[#Track Maintenance](#)
[#Undercarriage](#)

