



NESANS

MAINTENANCE TIPS

Mobile Jaw Crusher Hydraulic System: Troubleshooting Common Problems

Diagnose and fix mobile jaw crusher hydraulic issues. CSS adjustment, track drive, and conveyor fold problems with step-by-step solutions.

Author: Sivabalan
Selvarajan

Published: April 22,
2026

Reading Time: 8
minutes



Mobile jaw crushers rely heavily on hydraulic systems for critical functions including CSS adjustment, toggle protection, conveyor raising, track propulsion, and crusher clearing. Understanding these hydraulic circuits and their common failure modes enables operators to diagnose problems quickly and minimize downtime in field conditions where workshop facilities are limited.

Mobile Jaw Crusher Hydraulic System Architecture

Modern mobile jaw crushers integrate multiple hydraulic circuits that serve different functions. Understanding this architecture is essential for effective troubleshooting.

Primary Hydraulic Circuits

Most mobile jaw crushers incorporate several distinct hydraulic systems:

CIRCUIT	FUNCTION	TYPICAL PRESSURE	FLOW REQUIREMENT
CSS adjustment	Hydraulic toggle adjustment	200-280 bar	Low flow, high force
Tramp release	Protect from uncrushable material	250-350 bar preset	Accumulator backed
Track propulsion	Machine mobility	250-350 bar	High flow for speed
Conveyor fold	Transport configuration	150-200 bar	Medium flow
Feeder functions	Feeder height, grizzly angle	150-200 bar	Low flow

Hydraulic Power Unit Components

The central hydraulic power unit (HPU) supplies all circuits:

Key components and their functions:

- **Hydraulic reservoir:** Typically 150-300 litres, provides cooling and deaeration
- **Main pump:** Variable displacement piston pump, 80-150 L/min
- **Charge pump:** Fixed displacement gear pump for pilot circuits
- **Return filter:** 10-25 micron filtration before reservoir
- **Pressure filter:** 3-10 micron filtration on critical circuits
- **Oil cooler:** Air-oil or water-oil heat exchanger

- **Accumulator bank:** Nitrogen charged for tramp release

Common Hydraulic Problems and Diagnostic Procedures

Problem 1: CSS Adjustment Not Responding

The hydraulic CSS adjustment system is critical for maintaining product size specification. When it fails to respond, production quality suffers.

Symptoms:

- CSS setting doesn't change when adjustment is commanded
- Adjustment moves in one direction only
- Erratic or jerky movement during adjustment
- Hydraulic noise during adjustment attempts

Diagnostic procedure:

1. **Check hydraulic fluid level:** Low fluid causes pump cavitation and loss of pressure
2. **Verify system pressure:** Connect gauge to CSS circuit test point; should read 200-280 bar
3. **Check solenoid valve operation:** Listen for click when command is given
4. **Inspect cylinder for external leaks:** Check rod seal and port connections
5. **Verify toggle wear status:** Worn toggles may prevent adjustment range

Common causes and solutions:

CAUSE	DIAGNOSIS METHOD	SOLUTION
Solenoid valve failure	No click when activated, no flow	Replace solenoid coil or complete valve
Cylinder seal failure	External leak at rod, internal bypass	Reseal or replace cylinder
Relief valve stuck open	Low circuit pressure on gauge	Clean or replace relief valve

CAUSE	DIAGNOSIS METHOD	SOLUTION
Pump wear	Low flow at correct pressure	Check pump efficiency, replace if <80%
Blocked filter	High pressure drop across filter	Replace filter element

Problem 2: Tramp Iron Release System Failure

The tramp release system protects the crusher from catastrophic damage when uncrushable material enters. System failure puts the entire crusher at risk.

Symptoms:

- Crusher stalls instead of releasing on tramp iron
- Toggle plate breaks without accumulator release
- Accumulator pressure gauge shows low or zero pressure
- Relief valve chattering or leaking

Diagnostic procedure:

1. **Check accumulator pre-charge pressure:** Should be 60-70% of system working pressure
2. **Verify nitrogen pressure:** Use proper nitrogen charging kit, never use air
3. **Test relief valve setting:** Confirm opens at specified pressure (typically 280-350 bar)
4. **Check pilot circuit operation:** Verify pilot valve shifts correctly
5. **Inspect accumulator bladder:** Check for rupture or fatigue failure

Accumulator pre-charge specifications (typical):

SYSTEM PRESSURE	PRE-CHARGE PRESSURE	MINIMUM ACCEPTABLE
280 bar	170-190 bar	150 bar
320 bar	195-220 bar	175 bar
350 bar	210-240 bar	190 bar

Critical safety note: Accumulators store significant energy. Always follow proper lockout/tagout procedures and use nitrogen charging equipment rated for hydraulic accumulator service.

Problem 3: Track Drive System Issues

Track propulsion problems strand the machine, requiring costly heavy equipment transport.

Symptoms:

- One or both tracks won't move
- Slow track speed despite full throttle
- Track moves in one direction only
- Excessive track motor heating
- Jerky or uncontrollable track movement

Diagnostic procedure:

1. **Check pilot pressure:** Track controls require pilot circuit pressure (25-50 bar)
2. **Verify joystick/pedal function:** Check for broken cable, stuck valve
3. **Test track motor relief valves:** Cross-port reliefs protect from over-pressure
4. **Check final drive oil level:** Low level causes planetary gear damage
5. **Measure case drain flow:** Excessive flow indicates motor wear

Track drive troubleshooting table:

SYMPTOM	PROBABLE CAUSE	TEST METHOD	SOLUTION
No movement either direction	Pilot pressure failure	Check pilot pressure gauge	Repair pilot pump or relief
Slow movement only	Main pump low flow	Flow test pump output	Adjust/replace pump
Movement one direction only	Directional valve stuck	Manual valve override	Clean or replace valve
Excessive motor heating	Cross-port relief leaking	Infrared temperature check	Adjust or replace relief
Track won't hold on slope	Brake release valve failure	Check brake release pressure	Replace brake valve

Hydraulic Fluid Analysis and Maintenance

Proper hydraulic fluid condition is fundamental to system reliability. Mobile crushers operate in dusty environments that accelerate fluid contamination.

Fluid Contamination Control

Target cleanliness levels for mobile crusher hydraulics:

CIRCUIT TYPE	ISO CLEANLINESS TARGET	MAXIMUM ACCEPTABLE
Servo/proportional valves	16/14/11	17/15/12
Piston pumps and motors	17/15/12	18/16/13
Gear pumps and vane motors	18/16/13	19/17/14
Cylinders and general circuits	19/17/14	20/18/15

Fluid Analysis Parameters

Regular oil analysis provides early warning of developing problems:

Key analysis parameters:

- **Particle count:** ISO 4406 cleanliness code
- **Water content:** Karl Fischer titration, target <0.1%
- **Viscosity:** At 40°C, should be within $\pm 10\%$ of new oil
- **Total acid number (TAN):** Indicates oxidation, should be <2.0
- **Wear metals:** Iron, copper, bronze indicate component wear

Interpretation guidelines:

PARAMETER	NORMAL	CAUTION	CRITICAL
Iron (ppm)	<25	25-75	>75
Copper (ppm)	<15	15-40	>40
Silicon (ppm)	<15	15-25	>25
Water (%)	<0.05	0.05-0.1	>0.1

PARAMETER	NORMAL	CAUTION	CRITICAL
Viscosity change (%)	±5%	±5-10%	>±10%

Filter Maintenance Schedule

Filter condition directly impacts system cleanliness and component life:

FILTER LOCATION	CHANGE INTERVAL	BYPASS INDICATOR ACTION
Return filter	500 hours or indicator	Change immediately if triggered
Pressure filter	1000 hours or indicator	Change immediately, investigate cause
Pilot filter	500 hours	N/A - no bypass on most designs
Case drain filter	1000 hours	Change and sample for motor wear
Breather	250 hours or visual	Replace if discolored or damaged

Temperature Management

Hydraulic oil temperature affects viscosity, seal life, and overall system performance. Mobile crushers in Indian conditions face particular challenges during summer months.

Operating Temperature Limits

TEMPERATURE RANGE	SYSTEM STATUS	REQUIRED ACTION
30-50°C	Cold start range	Allow warm-up, avoid full load
50-70°C	Optimal operating range	Normal operation
70-80°C	Acceptable but elevated	Monitor, check cooler function
80-90°C	Warning range	Reduce load, investigate cooling
>90°C	Shutdown required	Stop immediately, prevent damage

Cooling System Troubleshooting

Oil cooler inspection checklist:

- Check cooler fins for debris blockage
- Verify cooling fan operation and direction
- Test thermostat valve operation (if equipped)
- Check cooler bypass valve setting
- Inspect for internal core blockage
- Verify adequate airflow around cooler

Temperature reduction strategies:

- Clean cooler cores daily in dusty conditions
- Install pre-filter screens on cooling air intake
- Consider upgrading to larger cooler for hot climate operation
- Ensure hydraulic tank is at proper fill level for heat dissipation
- Maintain proper oil viscosity grade for ambient conditions

Field Repair Procedures

Emergency Hose Repair

Hydraulic hose failures are common in the field. Proper temporary repairs get the machine operational while permanent repairs are arranged.

Essential field repair kit contents:

- Assorted reusable hose fittings (field-attachable)
- Hose lengths in common sizes (1/4", 3/8", 1/2", 3/4")
- O-rings for common fitting sizes
- Thread sealant tape and paste
- Adjustable wrenches and fitting tools
- Clean rags and plugs for open ports

Hose repair procedure:

1. Relieve system pressure completely
2. Clean area around fittings thoroughly
3. Remove damaged hose, plug open ports immediately
4. Measure required hose length accurately
5. Install new fittings with proper torque
6. Refill system and bleed air before starting

Cylinder Seal Replacement

External cylinder leaks can often be repaired in the field with proper preparation:

Field seal replacement procedure:

1. Fully retract cylinder and block securely
2. Remove gland retaining hardware
3. Extract gland and rod assembly
4. Clean all components thoroughly
5. Install new seal kit with proper orientation
6. Lubricate seals with clean hydraulic oil
7. Reassemble with proper torque sequence

Preventive Maintenance Schedule

Daily Checks

- Check hydraulic fluid level
- Inspect for visible leaks at all connections
- Monitor system temperature during operation
- Check accumulator pressure gauges
- Verify all functions operate correctly

Weekly/250-Hour Service

- Sample hydraulic fluid for analysis
- Clean oil cooler cores
- Check filter condition indicators
- Inspect hoses for wear, rubbing, weathering
- Verify all valve manual overrides function
- Check accumulator pre-charge pressure

Monthly/500-Hour Service

- Change return line filters
- Check pump case drain flow (wear indicator)
- Inspect cylinder rods for scoring or damage
- Test all relief valve settings
- Verify track drive final drive oil levels

Quarterly/1000-Hour Service

- Change all hydraulic filters
- Complete hydraulic fluid analysis
- Flush pilot circuit if contamination suspected
- Calibrate pressure gauges
- Check all hydraulic cylinder condition

Systematic hydraulic maintenance and rapid troubleshooting capability keeps mobile jaw crushers productive in demanding field conditions. Investing in proper diagnostic tools, spare parts inventory, and operator training delivers significant returns through reduced downtime and extended component life.

Topics:

#Hydraulics

#Maintenance

#Mobile Crusher

#Troubleshooting

