NESANS

TECHNICAL GUIDES

Aggregate Stockpile Segregation: Prevent Grade Contamination with Proper Management

Prevent stockpile segregation and maintain aggregate quality. Stacking methods, reclaiming techniques, and contamination control.

Author: Sivabalan Selvarajan

Published: May 1, 2026

Reading Time: 9 minutes



Aggregate stockpile segregation represents one of the most significant—yet frequently overlooked—causes of product quality problems in crushing operations. When material segregates in stockpiles, the resulting grade variation can cause batch-to-batch inconsistency that costs operations ₹2-5 lakh monthly in customer complaints, rejected loads, and price penalties. Understanding segregation mechanisms and implementing proper stockpile management can virtually eliminate this problem, ensuring consistent product quality that meets IS 383 specifications for every load.

Understanding Segregation Mechanisms

What Causes Segregation

Segregation occurs when particles of different sizes separate during stockpile formation and material handling. Three primary mechanisms drive this separation:

Trajectory Segregation: When material is discharged from a conveyor or dropped from height, larger particles travel further than smaller particles due to their greater momentum. This creates zones of different gradation across the stockpile face.

Percolation Segregation: Smaller particles filter down through the voids between larger particles as material flows down the stockpile face. This concentrates fines at the pile interior and base while coarse material accumulates at the surface and toe.

Fluidization Segregation: Fine particles become airborne during material discharge and settle in different locations than the bulk material, creating dust deposits with abnormal gradation.

Factors Affecting Segregation Severity

FACTOR	EFFECT ON SEGREGATION	MITIGATION APPROACH
Drop height	Higher drop = more segregation	Minimize freefall distance, use rock ladders
Particle size range	Wider range = more segregation	Narrow product specifications where possible
Moisture content	Dry material segregates more	Maintain optimal moisture (2-4%)

FACTOR	EFFECT ON SEGREGATION	MITIGATION APPROACH
Particle shape	Rounded particles segregate more	Limited control; affects handling method choice
Stockpile height	Higher piles = more percolation	Limit pile height to 10-12m maximum
Wind conditions	Wind increases fines separation	Windbreaks, moisture control

Measuring Segregation Impact

Gradation Variation Analysis

Quantify segregation by sampling from different stockpile locations and comparing gradations. A properly managed stockpile should show less than 5% variation on any sieve size between sampling locations.

Sampling protocol for segregation assessment:

1. Sample from pile top (center and two edges)
2. Sample from pile face at three heights (top, middle, bottom)
3. Sample from pile toe (three locations around perimeter)
4. Run complete gradation analysis on each sample
5. Calculate standard deviation for each sieve size

Interpreting results:

STANDARD DEVIATION	SEGREGATION LEVEL	ACTION REQUIRED
<2%	Minimal	Current practices adequate
2-5%	Moderate	Implement improvements
5-10%	Severe	Immediate action required
>10%	Critical	Stop operations until resolved

Economic Impact Calculation

Calculate the cost of segregation-related quality problems:

Direct costs:

- Rejected loads requiring reprocessing: ₹150-300/tonne reblending cost
- Customer complaints and credits: ₹200-500/tonne price reduction
- Load-specific testing costs: ₹500-1,500 per test

Indirect costs:

- Customer relationship damage and lost sales
- Production delays for reprocessing
- Increased testing frequency requirements

Example calculation: Operation producing 300 TPH, 10-hour shifts, experiencing 5% rejection rate due to gradation variation:

- Daily rejection: 3,000 × 0.05 = 150 tonnes
- Reblending cost: 150 × ₹200 = ₹30,000/day
- Monthly impact: ₹30,000 × 25 = ₹7.5 lakh

Stockpile Design for Minimum Segregation

Optimal Stockpile Geometry

Stockpile design significantly affects segregation severity. Key design parameters:

Cone vs. Windrow: Conical stockpiles maximize segregation because material flows down all sides equally, creating concentric rings of different gradation. Windrow (linear) stockpiles allow reclaim from the cross-section, which naturally blends material from different zones.

Height limitations: Limit conical stockpile height to 10-12m maximum. Each additional meter of height increases percolation segregation. For critical applications requiring tight gradation control, limit height to 6-8m.

Angle of repose: Steeper angles (35-40°) create faster material flow down the face, increasing trajectory segregation. Manage material moisture and fines content to achieve flatter angles (30-35°) where possible.

Stacking Strategies

Layer building (chevron stacking): Build stockpiles in thin layers by moving the stacking point across the pile footprint. This distributes gradation variation throughout the pile rather than concentrating it radially.

Radial stacking: The most common but worst method for segregation. A fixed stacking point builds a cone with severe segregation. Use only when other methods are impractical.

Windrow stacking: Build linear piles by moving the stacking point along the pile length. Subsequent reclaim cuts through all deposited layers, providing natural blending.

STACKING METHOD	SEGREGATION TENDENCY	BLENDING EFFECTIVENESS	APPLICATION
Chevron (traveling tripper)	Low	Excellent	High-volume, quality-critical
Windrow	Moderate	Good	Medium-volume, general use
Cone and shell	Moderate-high	Fair	Space-limited operations
Radial (fixed point)	High	Poor	Avoid for graded products

Reclaim Strategies for Consistent Gradation

Cross-Section Reclaim

The key to eliminating segregation impact is reclaiming across the full stockpile cross-section. This naturally blends material from all segregation zones:

Front-end loader technique:

1. Attack the pile face perpendicular to the stockpile axis
2. Take full-height cuts from base to top
3. Rotate bucket to capture material from all heights

4. Avoid partial-height cuts that sample only one zone

Reclaimer systems: Bucket wheel or scraper reclaimers automatically cut across the full stockpile section, providing consistent blending. These systems are most effective with chevron or windrow stacking methods.

Avoiding Single-Zone Reclaim

Never reclaim from a single location for extended periods. Common mistakes:

- **Toe reclaim only:** Yields coarse-biased product from percolation zone
- **Top skimming:** Yields coarse-biased product from trajectory zone
- **Center tunneling:** Yields fines-rich product from percolation core
- **Edge mining:** Yields variable product depending on deposition history

Real-Time Quality Management

Sampling Frequency

Establish sampling protocols that detect segregation-related variation before product ships:

PRODUCT TYPE	MINIMUM SAMPLING	CRITICAL SIEVES
Concrete aggregate	Every 500 tonnes	4.75mm, 10mm, 20mm
Asphalt aggregate	Every 300 tonnes	2.36mm, 4.75mm, 10mm
Road base	Every 1,000 tonnes	4.75mm, 20mm, 40mm
Manufactured sand	Every 250 tonnes	150µm, 300µm, 600µm

Control Charts

Implement statistical process control (SPC) to detect gradation drift before it causes specification failures:

Setting up control charts:

1. Establish baseline from 20+ samples under normal operation

2. Calculate mean and standard deviation for each critical sieve
3. Set warning limits at ±2 standard deviations
4. Set action limits at ±3 standard deviations
5. Plot each sample result and monitor trends

Response to control chart signals:

- **Single point outside warning:** Increase sampling frequency
- **Two consecutive points outside warning:** Investigate reclaim method
- **Point outside action limit:** Stop shipping, investigate cause
- **Trend toward limit:** Proactive investigation before violation

Equipment and Systems for Segregation Control

Rock Ladders and Flow Control

Rock ladders reduce drop height and control material flow velocity, significantly reducing trajectory segregation:

Design considerations:

- Maximum freefall between shelves: 2-3m
- Shelf angle: 35-45° for controlled flow
- Shelf material: Wear-resistant steel or rubber lining
- Position: At conveyor discharge, bin outlets, transfer points

Telescopic chutes: Adjustable-length chutes maintain constant drop height as stockpile grows. More effective than rock ladders for new material placement.

Spreader Systems

Mechanical spreaders distribute material across a wider area, reducing point loading:

- **Traveling trippers:** Move stacking point along conveyor length
- **Rotary distributors:** Spread material in circular pattern
- **Vibrating spreaders:** Use vibration to distribute material laterally

Moisture Addition Systems

Controlled moisture addition reduces segregation by increasing particle cohesion:

Optimal moisture range: 2-4% for most aggregate products. Higher moisture increases cohesion but may cause handling problems and customer complaints.

Application points:

- At crusher discharge (combines with dust suppression)
- At screen discharge (product-specific application)
- At stockpile stacking point (final treatment)

Operational Best Practices

Loader Operator Training

Train loader operators in segregation-aware reclaim techniques:

PRACTICE	WHY IT MATTERS	TRAINING METHOD
Full-face cuts	Blends all segregation zones	Visual demonstration, supervision
Consistent bucket filling	Maintains gradation consistency	Weigh test loads, feedback
Rotate reclaim points	Avoids single-zone mining	Marked reclaim zones, schedule
Recognize gradation changes	Early problem detection	Sample identification training

Shift Communication

Establish communication protocols for gradation-related issues:

- Shift handover includes stockpile status and any gradation concerns
- Quality lab communicates sample results within 30 minutes
- Out-of-spec results trigger immediate notification to plant operator
- Daily production meeting reviews gradation trends

Documentation and Traceability

Maintain records that allow issue investigation:

- Stockpile deposition records (time, volume, source)
- Reclaim records (location, time, destination)
- Quality test results with sample location identification
- Customer delivery records linked to stockpile/reclaim records

Troubleshooting Segregation Problems

Problem: Consistent Coarse Bias

Likely causes:

- Reclaim focused on pile toe and edges
- Insufficient moisture allowing fines to percolate
- Excessive drop height at stacking point

Solutions:

- Implement full-face reclaim protocol
- Increase moisture to 3-4%
- Install rock ladder or reduce stacking height

Problem: Consistent Fine Bias

Likely causes:

- Reclaim tunneling into pile center
- Wind-blown fines contamination
- Upstream screening problems

Solutions:

- Expand reclaim to full cross-section
- Install windbreaks, clean affected areas
- Check screen efficiency and apertures

Problem: Erratic Gradation Variation

Likely causes:

- Multiple products commingled in stockpile
- Inconsistent reclaim practices between operators
- Source material gradation changes

Solutions:

- Dedicate stockpiles to single products
- Standardize and train reclaim procedures
- Monitor and control crusher settings

Case Study: Gradation Stabilization

A 250 TPH aggregate operation experienced 8% rejection rate due to gradation variation in their 20mm product. Investigation revealed:

Problems identified:

- 15m stockpile height with fixed radial stacking
- Loader operators reclaiming from convenient locations
- No moisture addition at stockpile
- Sampling only from loaded trucks

Solutions implemented:

- Limited pile height to 8m with windrow stacking
- Trained operators on full-face reclaim, marked zones
- Added moisture spray at stacking conveyor discharge
- Implemented stockpile sampling protocol

Results after 3 months:

- Rejection rate: 8% → 0.5%
- Gradation standard deviation: 7.2% → 2.1%
- Monthly cost savings: ₹4.2 lakh (reduced rejections, testing, complaints)

- Implementation cost: ₹1.8 lakh (training, equipment, moisture system)
- Payback period: 13 days

Conclusion

Aggregate stockpile segregation is a solvable problem that many operations overlook. The combination of proper stacking methods, appropriate stockpile geometry, full-face reclaim practices, and moisture management can reduce gradation variation from 10% + to under 3%. The economic benefits of consistent product quality—including reduced rejections, fewer customer complaints, and premium pricing potential—typically return 5-10× the implementation investment within the first year. Start with the basics: limit pile height, train operators on proper reclaim technique, and implement systematic sampling. Build from there with engineering controls like rock ladders and moisture systems. Your customers will notice the difference in product consistency, and your bottom line will reflect the improvement.

Topics: #Stockpile Management #aggregate quality #material handling

NESANS
www.nesansindia.in
SF No 20/1, Eachanary Madukkarai Road, Coimbatore, TN 641024
+91 9578 799 755