NESANS

MAINTENANCE TIPS


Crusher Electrical Protection: Prevent Motor Burnout with Proper Relay Settings

Set up electrical protection for crusher motors. Overload relays, phase protection, and trip settings to prevent costly motor failures.

Author: Sivabalan Selvarajan

Published: April 28, 2026

Reading Time: 7 minutes



Quarry blasting is the critical first step in aggregate production, and blast design decisions made in the quarry directly impact crusher performance, wear costs, and product quality in the processing plant. Many operations treat blasting and crushing as separate functions, missing the opportunity to optimize the complete system. Poor fragmentation from suboptimal blasting can reduce crusher throughput by 30-40% while dramatically increasing wear rates and energy consumption. Understanding the relationship between blast design and crusher requirements enables optimization that benefits the entire operation.

Understanding the Blasting-Crushing Connection

How Fragmentation Affects Crushing

Rock fragmentation from blasting determines the size distribution of material entering the primary crusher. This distribution directly affects:

- **Crusher feed acceptance:** Oversized material causes bridging and blockages
- **Throughput rate:** Finer fragmentation enables higher feed rates
- **Crushing ratio required:** Coarser feed requires more size reduction stages
- **Wear rates:** Larger pieces cause more impact wear
- **Energy consumption:** Crushing consumes 20-30× more energy than blasting

Economic Impact Quantification

Consider a 500 TPH quarry operation comparing optimal vs. poor fragmentation:

FACTOR	POOR FRAGMENTATION	OPTIMAL FRAGMENTATION	DIFFERENCE
Effective throughput	350 TPH (70%)	475 TPH (95%)	+125 TPH
Crushing energy (kWh/t)	3.2	2.4	-25%
Liner life (hours)	2,500	3,800	+52%
Secondary breaking cost	₹15/tonne	₹3/tonne	-80%

FACTOR	POOR FRAGMENTATION	OPTIMAL FRAGMENTATION	DIFFERENCE
Annual operating cost difference	₹1.5-2.5 crore (for 1.5 million tonne/year operation)		

The "Mine to Mill" Concept

Mine to Mill optimization recognizes that increasing blast energy costs is often economically justified by larger savings in crushing and grinding. The key insight: energy applied in blasting is 20-30× more efficient at breaking rock than mechanical crushing.

Example economics:

- Blasting cost increase: ₹2-3/tonne for finer fragmentation
- Crushing cost reduction: ₹8-15/tonne from improved throughput and efficiency
- Net benefit: ₹6-12/tonne

Blast Design Parameters Affecting Crushing

Burden and Spacing

Burden (distance from blast hole to free face) and spacing (distance between holes) are the primary controls on fragmentation:

PARAMETER	EFFECT OF INCREASING	IMPACT ON CRUSHING
Burden	Coarser fragmentation, more boulders	Reduced throughput, more secondary breaking
Spacing	Coarser fragmentation in toe	More oversize, bridging problems
Burden/Spacing ratio	Affects uniformity of breakage	Variable feed sizing, inconsistent loading

Optimal ratios for crusher feed:

- Burden: 25-35× hole diameter
- Spacing: 1.1-1.3× burden

- Target P80: 60-70% of primary crusher feed opening

Powder Factor

Powder factor (explosive quantity per unit rock volume) directly controls energy input and fragmentation fineness:

ROCK TYPE	TYPICAL POWDER FACTOR (KG/M³)	EFFECT ON FRAGMENTATION
Soft limestone	0.25-0.35	Fine, uniform breakage
Medium granite	0.35-0.50	Moderate, may need adjustment
Hard basalt	0.45-0.65	Requires higher energy input
Fractured/weathered	0.20-0.35	Over-breakage risk if too high

Optimization approach:

1. Measure actual fragmentation distribution (photo analysis or screening)
2. Compare to crusher feed requirements
3. Adjust powder factor to achieve target P80
4. Balance cost increase against crushing benefits

Timing and Sequencing

Blast timing affects fragmentation uniformity and muckpile characteristics:

Short delays (15-25ms between rows):

- Tighter, more confined muckpile
- Finer, more uniform fragmentation
- Better for crusher feed consistency

Long delays (40-65ms between rows):

- Looser, more spread muckpile
- Coarser fragmentation, more oversize
- Easier digging but harder crushing

Hole Diameter Selection

Hole diameter affects both blast efficiency and fragmentation:

HOLE DIAMETER	FRAGMENTATION EFFECT	COST IMPACT
Small (75-100mm)	Finer, more uniform	Higher drilling cost, lower explosive cost
Medium (115-140mm)	Balanced performance	Moderate total cost
Large (165-200mm)	Coarser, more variable	Lower drilling cost, higher explosive cost

Smaller holes with tighter patterns generally produce better fragmentation for crushing, but total drilling and blasting cost must be considered.

Measuring Fragmentation for Crusher Optimization

Photo Analysis Methods

Modern image analysis systems provide rapid, accurate fragmentation measurement:

Implementation:

1. Capture images of muckpile or truck loads
2. Software identifies and measures individual rocks
3. Generates size distribution curve (P10, P50, P80, P100)
4. Compares to target specifications

Key metrics for crusher feed:

- **P80:** 80% passing size—should be 60-70% of crusher feed opening
- **P100:** Maximum size—should not exceed crusher feed opening
- **Uniformity coefficient:** Measures distribution spread—lower is more uniform

Monitoring Crusher Response

Track crusher performance metrics to correlate with blast design:

METRIC	INDICATOR OF GOOD FRAGMENTATION	INDICATOR OF POOR FRAGMENTATION
Throughput rate	Consistent at rated capacity	Variable, frequently below target
Power draw	Steady at 80-90% of rated	Fluctuating, frequent spikes
Bridging frequency	Rare (once per shift or less)	Frequent (multiple per hour)
Secondary breaking need	Minimal (5% of material)	Frequent (>20% of material)

Optimizing Blast Design for Crusher Feed

Target Fragmentation Sizing

Establish target fragmentation based on primary crusher specifications:

For jaw crushers:

- Target P80: 60-65% of feed opening width
- Maximum size (P100): 85-90% of feed opening width
- Allow for occasional oversize requiring breaking

For gyratory crushers:

- Target P80: 55-60% of feed opening
- More sensitive to oversize due to choke point
- Tighter fragmentation control required

Example: For a 1200×900mm jaw crusher (900mm feed opening width):

- Target P80: 540-585mm
- Maximum size: 765-810mm
- Anything larger requires secondary breaking

Rock Type Considerations

Different rock types respond differently to blasting and affect crusher behavior:

ROCK TYPE	BLAST RESPONSE	CRUSHER IMPACT	OPTIMIZATION FOCUS
Hard, massive granite	Breaks along blast fractures	High wear, blocky product	Higher powder factor, tighter patterns
Laminated limestone	Breaks along bedding planes	Slab production, bridging risk	Timing for cross-break, smaller holes
Weathered rock	Over-breaks easily	Excessive fines, may blind screens	Lower powder factor, controlled blast
Competent basalt	Requires high energy	Excellent product, high wear	Maximum powder factor practical

Muckpile Configuration

Muckpile shape affects loading efficiency and crusher feed consistency:

Ideal muckpile characteristics:

- Uniform fragmentation throughout pile
- No segregation of fines and coarse
- Optimal throw for loading equipment access
- Minimal oversize on surface

Blast design for good muckpile:

- Front row timing creates initial throw
- Back row timing controls final pile shape
- Appropriate stemming prevents cratering
- Controlled throw prevents excessive spread

Handling Poor Fragmentation at the Crusher

Secondary Breaking Options

When blasting produces oversize material, secondary breaking is required:

METHOD	CAPACITY	COST PER TONNE BROKEN	BEST APPLICATION
Hydraulic rock breaker	50-150 t/hr (of oversize)	₹25-50	Regular oversize handling
Drop ball	30-80 t/hr	₹15-30	Large boulders, low tech
Secondary blasting	Variable	₹10-20	Massive boulders, unsafe for breaker
Grizzly scalping	Continuous	₹5-10 (diversion cost)	Consistent oversize percentage

Grizzly Feeder Optimization

Grizzly feeders ahead of the crusher can manage variable fragmentation:

Bar spacing selection:

- Bars spaced at 60-70% of crusher CSS
- Removes fines that consume crusher energy
- Provides buffer for feed rate variation

Handling oversize:

- Reject chute directs oversize to breaker pad
- Reduces crusher blockages
- Maintains consistent feed to crusher

Communication and Feedback Systems

Blast-to-Crush Feedback Loop

Establish formal communication between blasting and crushing operations:

Data to share from crushing to blasting:

- Crusher throughput achieved vs. target
- Bridging and blockage frequency
- Secondary breaking tonnage required

- Wear rates and liner life

Data to share from blasting to crushing:

- Blast design parameters used
- Actual powder factor achieved
- Photo analysis fragmentation results
- Any anomalies or deviations

Optimization Meetings

Regular meetings between drilling/blasting and crushing teams:

- Weekly review of performance metrics
- Monthly analysis of cost impacts
- Quarterly optimization trials
- Annual strategic review and goal setting

Case Study: Fragmentation Optimization

A 400 TPH granite quarry optimized blast design for crusher performance:

Initial condition:

- Powder factor: 0.38 kg/m³
- Burden: 3.5m, Spacing: 4.0m
- P80 fragmentation: 520mm
- Crusher throughput: 320 TPH (80% of rated)
- Secondary breaking: 18% of material

Optimized design:

- Powder factor: 0.48 kg/m³ (+26%)
- Burden: 3.0m, Spacing: 3.5m (tighter pattern)
- P80 fragmentation: 380mm (-27%)
- Crusher throughput: 385 TPH (96% of rated)
- Secondary breaking: 4% of material

Economic result:

COST CATEGORY	BEFORE	AFTER	CHANGE
Blasting cost/tonne	₹18	₹24	+₹6
Secondary breaking/tonne	₹9	₹2	-₹7
Crushing cost/tonne	₹42	₹35	-₹7
Lost production value	₹12	₹2	-₹10
Net savings/tonne			**₹18**
Annual savings (1.2M tonnes)	₹2.16 crore		

Conclusion

Quarry blasting and crusher performance are inseparably linked. Optimizing blast design for crusher feed—rather than minimizing blast cost alone—typically reduces total production cost by ₹10-25 per tonne. The key is treating drilling, blasting, and crushing as an integrated system rather than separate operations. Establish fragmentation targets based on crusher requirements, measure actual fragmentation systematically, and maintain regular communication between blasting and crushing teams. The additional investment in blast optimization returns many times its cost through improved crusher throughput, reduced energy consumption, extended wear life, and minimized secondary breaking requirements. Make fragmentation measurement and blast-crush feedback loops standard practice in your operation.

Topics: #Crusher #Electrical Protection #Motor Maintenance