



**NESANS**

**TECHNICAL GUIDES**

# Hydrocyclone Cut Point Optimization: Achieve Target Sand Gradation Consistently

Optimize hydrocyclone cut point for consistent sand gradation. Apex sizing, feed pressure control, and troubleshooting for sand classification.

**Author:** Sivabalan  
Selvarajan

**Published:** May 13,  
2026

**Reading Time:** 6  
minutes



Hydrocyclones are critical for controlling sand gradation in manufactured sand and sand washing operations. The cut point—the particle size at which 50% reports to underflow and 50% to overflow—determines product quality and fines recovery. Understanding the factors affecting cut point and how to optimize cyclone performance enables operators to consistently achieve target sand specifications.

## Understanding Hydrocyclone Operation

### Basic Operating Principle

Hydrocyclones use centrifugal force to classify particles by size:

1. **Feed entry:** Slurry enters tangentially at pressure
2. **Vortex formation:** Rotation creates centrifugal force
3. **Classification:** Coarse particles forced to wall, fines stay central
4. **Underflow:** Coarse particles exit through apex (spigot)
5. **Overflow:** Fine particles exit through vortex finder

### Key Cyclone Parameters

PARAMETER	SYMBOL	TYPICAL RANGE	EFFECT ON CUT POINT
Cyclone diameter	$D_c$	100-650mm	Larger = coarser cut
Vortex finder diameter	$D_o$	$0.25-0.40 \times D_c$	Larger = coarser cut
Apex (spigot) diameter	$D_u$	$0.10-0.35 \times D_c$	Larger = coarser cut
Feed pressure	$P$	50-150 kPa	Higher = finer cut
Feed density	$\rho$	20-40% solids	Higher = coarser cut
Inlet diameter	$D_i$	$0.20-0.30 \times D_c$	Affects flow pattern

### Cut Point Definition

The d50 cut point is the particle size with equal probability of reporting to either product:

d50 = particle size where:

- 50% of particles report to underflow
- 50% of particles report to overflow

Corrected d50c accounts for bypass (water and fines short-circuiting to underflow):  
d50c provides truer separation efficiency measure

## Factors Affecting Cut Point

### Geometric Factors

FACTOR	CHANGE	CUT POINT EFFECT	TYPICAL ADJUSTMENT RANGE
Cyclone diameter	Larger	Coarser cut	Select appropriate size
Vortex finder diameter	Larger	Coarser cut	±10-20% of standard
Apex diameter	Larger	Coarser cut	Wide range available
Cone angle	Steeper	Slightly finer	Usually fixed by design
Vortex finder length	Longer	Finer cut	±25% of standard

### Operating Factors

FACTOR	CHANGE	CUT POINT EFFECT	NOTES
Feed pressure	Higher	Finer cut	Also increases capacity
Feed density	Higher	Coarser cut	Affects efficiency
Feed rate	Higher	Coarser cut	Linked to pressure
Particle density	Higher	Finer cut	Material property
Viscosity	Higher	Coarser cut	Temperature dependent

### Cut Point Estimation

Plitt equation for estimating cut point:

$$d_{50c} = 14.8 \times D_c^{0.46} \times D_i^{0.6} \times D_o^{1.21} \times \exp(0.063 \times \% \text{solids}) / (D_u^{0.71} \times h^{0.38} \times Q^{0.45} \times (\rho_s - \rho_l)^{0.5})$$

Where:

$D_c$  = cyclone diameter (cm)

$D_i$  = inlet diameter (cm)

$D_o$  = vortex finder diameter (cm)

$D_u$  = apex diameter (cm)

$h$  = free vortex height (cm)

$Q$  = volumetric feed rate (L/min)

$\rho_s$  = solids density (g/cm<sup>3</sup>)

$\rho_l$  = liquid density (g/cm<sup>3</sup>)

## Apex (Spigot) Selection and Adjustment

### Apex Sizing Guidelines

The apex diameter is the primary operating adjustment for cut point control:

#### Selection criteria:

- Must be large enough to discharge all underflow solids
- Should produce "rope" or "spray" discharge as required
- Smaller apex = finer cut, but risk of roping/plugging
- Larger apex = coarser cut, more water to underflow

#### Apex to vortex finder ratio (Du/Do):

DU/DO RATIO	DISCHARGE TYPE	APPLICATION
0.25-0.35	Spray discharge	Normal classification
0.35-0.45	Transition	High underflow density
>0.45	Rope discharge risk	Avoid unless intended

### Discharge Pattern Interpretation

DISCHARGE PATTERN	INDICATION	ACTION
Wide spray (20-30° cone)	Underloaded, too much water	Reduce apex or increase feed density

DISCHARGE PATTERN	INDICATION	ACTION
Narrow spray (10-20° cone)	Normal operation	Maintain current settings
Rope (dense stream)	Overloaded, risk of plugging	Increase apex size immediately
Intermittent/pulsing	Air core unstable	Check feed consistency, pressure

## Vortex Finder Adjustment

### Vortex Finder Effects

The vortex finder controls overflow capacity and cut point:

CHANGE	EFFECT ON CUT POINT	EFFECT ON CAPACITY	OTHER EFFECTS
Larger diameter	Coarser	Higher overflow	More fines to overflow
Smaller diameter	Finer	Lower overflow	Higher pressure required
Longer insertion	Finer	Slight decrease	Reduces short-circuit
Shorter insertion	Coarser	Slight increase	More short-circuiting

### Vortex Finder Selection

Standard sizes available for each cyclone diameter:

CYCLONE DIAMETER	STANDARD VF DIAMETER	OPTIONAL SIZES
250mm	90mm	75, 80, 100, 110mm
380mm	140mm	120, 130, 150, 160mm
500mm	180mm	160, 170, 190, 200mm
650mm	230mm	200, 215, 245, 260mm

# Feed Pressure Optimization

## Pressure Effects

Feed pressure significantly affects cyclone performance:

Cut point relationship:  
 $d_{50} \propto 1 / \sqrt{P}$  (approximately)

Doubling pressure reduces cut point by ~30%

Capacity relationship:  
 $Q \propto \sqrt{P}$

Doubling pressure increases capacity by ~40%

## Optimal Pressure Ranges

APPLICATION	RECOMMENDED PRESSURE	NOTES
Coarse sand classification	50-80 kPa	Lower pressure, larger cyclone
Fine sand classification	80-120 kPa	Medium pressure, medium cyclone
Ultra-fines removal	120-180 kPa	High pressure, small cyclone
Desliming/dewatering	100-150 kPa	Dense underflow target

## Pressure Monitoring

Monitor pressure to maintain consistent cut point:

- Install pressure gauge at cyclone inlet manifold
- Record pressure with each sample analysis
- Maintain  $\pm 10\%$  of target pressure
- Adjust pump speed or valve to control pressure

## Feed Density Control

---

### Density Effects

Feed solids concentration affects classification efficiency:

FEED DENSITY	CUT POINT EFFECT	EFFICIENCY EFFECT
Low (<15% solids)	Finest cut	Best efficiency, but low capacity
Optimal (20-30% solids)	Target cut	Good efficiency and capacity
High (>35% solids)	Coarser cut	Reduced efficiency, poor separation

### Density Control Methods

- **Dilution water addition:** Add water to sump to reduce density
- **Feed rate control:** Reduce solids feed rate to lower density
- **Pump speed adjustment:** Match pump output to maintain density
- **Automatic density control:** Use density sensor with feedback loop

## Achieving Target Sand Gradation

---

### IS 383 Zone II Sand Requirements

For manufactured sand targeting IS 383 Zone II:

SIEVE SIZE	ZONE II PASSING (%)	CYCLONE ROLE
4.75mm	90-100	Feed preparation
2.36mm	75-100	Feed preparation
1.18mm	55-90	Not directly controlled
600µm	35-59	Not directly controlled
300µm	8-30	Critical cut zone
150µm	0-10	Removal target

## Typical cyclone cut point for M-sand:

- d50c = 75-100 microns to achieve 0-10% passing 150µm
- Must balance fines removal vs product yield loss

## Gradation Control Strategy

1. **Establish baseline:** Measure current feed and product gradations
2. **Calculate required cut:** Determine d50 needed for specification
3. **Select cyclone size:** Match capacity and cut point requirements
4. **Optimize settings:** Adjust apex, VF, pressure for target
5. **Monitor and adjust:** Sample regularly and fine-tune

## Multi-Stage Classification

---

### Two-Stage Cyclone Circuits

For tighter gradation control, use multiple stages:

#### Circuit configurations:

CONFIGURATION	PURPOSE	APPLICATION
Series overflow	Progressive fines removal	Desliming fine sands
Parallel operation	Increased capacity	High throughput requirements
Series underflow	Multiple products	Sand and gravel separation

### Cyclone Cluster Design

Multiple small cyclones vs single large cyclone:

ASPECT	SINGLE LARGE	CLUSTER OF SMALL
Cut point	Coarser	Finer possible
Efficiency	Good	Better

ASPECT	SINGLE LARGE	CLUSTER OF SMALL
Maintenance	Easier	More items
Redundancy	None	Partial operation possible
Cost	Lower	Higher

## Troubleshooting Cyclone Performance

### Cut Point Too Coarse

SYMPTOM	POSSIBLE CAUSE	SOLUTION
Excess fines in overflow	Feed pressure too low	Increase pump speed or pressure
Coarse in underflow	Apex too large	Install smaller apex
Poor separation	Feed density too high	Add dilution water
Wide spray discharge	Underloaded cyclone	Reduce apex or increase feed

### Cut Point Too Fine

SYMPTOM	POSSIBLE CAUSE	SOLUTION
Product too coarse	Feed pressure too high	Reduce pressure
Low underflow rate	Apex too small	Install larger apex
Rope discharge	Apex plugging	Immediately increase apex size
Excessive fines loss	VF too large	Install smaller vortex finder

### Poor Efficiency

SYMPTOM	POSSIBLE CAUSE	SOLUTION
Fines in underflow	Short-circuiting	Extend vortex finder

SYMPTOM	POSSIBLE CAUSE	SOLUTION
Coarse in overflow	Disturbed flow pattern	Check for air leaks, worn parts
Variable cut point	Feed fluctuation	Stabilize feed pressure and density
Low sharpness	Worn components	Inspect and replace liners

## Maintenance Requirements

---

### Wear Component Inspection

COMPONENT	INSPECTION INTERVAL	REPLACEMENT CRITERIA
Apex liner	Daily visual	Worn to 110% of nominal ID
Vortex finder	Weekly	Worn, cracked, or deformed
Inlet liner	Monthly	Significant wear or grooving
Cone liner	Monthly	Through-wear or pitting
Feed chamber	Monthly	Erosion affecting flow pattern

### Performance Monitoring

- Sample underflow and overflow daily
- Track d50 cut point over time
- Record pressure and discharge pattern
- Calculate and trend classification efficiency
- Correlate performance changes with wear status

Consistent hydrocyclone performance requires understanding the relationships between geometry, operating conditions, and cut point. Regular monitoring, proper maintenance, and systematic optimization enable operators to achieve and maintain target sand gradations reliably.

**Topics:**

#Hydrocyclone

#Sand Classification

#sand washing